
CONGOTALI

REQUIREMENT OF A PRESERVATIVE TREATMENT

Against dry wood borer attacks:	Does not require any preservative treatment
In case of temporary humidification risk:	Does not require any preservative treatment
In case of permanent humidification risk:	Does not require any preservative treatment

DRYING

Possible drying schedule

Drying rate:	Slow	Temperature (°C)			Air humidity (%)
		M.C. (%)	dry-bulb	wet-bulb	
Risk of distortion:	High risk	Green	40	37	82
Risk of casehardening:	No	40	44	38	68
Risk of checking:	High risk	30	44	36	59
Risk of collapse:	No	20	46	36	52
		15	49	37	46

This schedule is given for information only and is applicable to thickness < 38 mm.

It must be used in compliance with the code of practice.

For thickness from 38 to 75 mm , the air relative humidity should be increased by 5 % at each step.

For thickness over 75 mm , a 10 % increase should be considered.

SAWING AND MACHINING

Blunting effect:	High
Sawteeth recommended:	Stellite-tipped
Cutting tools:	Tungsten carbide
Peeling:	Not recommended or without interest
Slicing:	Not recommended or without interest
Note:	Must be sawn with the highest moisture content possible.

ASSEMBLING

Nailing / Screwing:	Good but pre-boring necessary
Gluing:	Correct (for interior only)
Note:	Gluing must be done with care (very dense wood).

END-USES

Main known end-uses; they must to be implemented according to the code of practice.

Important remark: some end-uses are mentionned for information (traditional, regional or ancient end-uses).

Note: Can be used as substitute for AZOBE (*Lophira alata*).

Hydraulic works (fresh water)
Bridges (parts in contact with water or ground)
Sleepers
Industrial or heavy flooring
Vehicle or container flooring
Heavy carpentry
Bridges (parts not in contact with water or ground)
