
CURUPIXA

REQUIREMENT OF A PRESERVATIVE TREATMENT

Against dry wood borer attacks:	Requires appropriate preservative treatment
In case of temporary humidification risk:	Requires appropriate preservative treatment
In case of permanent humidification risk:	Use not recommended

DRYING

Possible drying schedule

Drying rate:	Rapid to normal	Temperature (°C)			Air humidity (%)
		M.C. (%)	dry-bulb	wet-bulb	
Risk of distortion:	Slight risk	Green	42	39	82
Risk of casehardening:	No	50	48	43	74
Risk of checking:	Slight risk	40	48	43	74
Risk of collapse:	No	30	48	43	74
		15	54	46	63

This schedule is given for information only and is applicable to thickness < 38 mm.

It must be used in compliance with the code of practice.

For thickness from 38 to 75 mm , the air relative humidity should be increased by 5 % at each step.

For thickness over 75 mm , a 10 % increase should be considered.

SAWING AND MACHINING

Blunting effect:	Fairly high
Sawteeth recommended:	Stellite-tipped
Cutting tools:	Tungsten carbide
Peeling:	Good
Slicing:	Good
Note:	Variable silica content according to the species.

ASSEMBLING

Nailing / Screwing:	Good
Gluing:	Correct

END-USES

Main known end-uses; they must to be implemented according to the code of practice.

Important remark: some end-uses are mentionned for information (traditional, regional or ancient end-uses).

Interior joinery
Interior panelling
Light carpentry
Current furniture or furniture components
Flooring
Stairs (inside)
Turned goods
Wood-ware
Exterior joinery
Veneer for interior of plywood
Veneer for back or face of plywood
Cabinetwork (high class furniture)
Sliced veneer
