
QUARUBA

REQUIREMENT OF A PRESERVATIVE TREATMENT

Against dry wood borer attacks:	Requires appropriate preservative treatment
In case of temporary humidification risk:	Requires appropriate preservative treatment
In case of permanent humidification risk:	Use not recommended

DRYING

Possible drying schedule

Drying rate:	Normal to slow	Temperature (°C)			Air humidity (%)
		M.C. (%)	dry-bulb	wet-bulb	
Risk of distortion:	High risk	Green	42	39	82
Risk of casehardening:	No	50	48	43	74
Risk of checking:	Slight risk	40	48	43	74
Risk of collapse:	Yes	30	48	43	74
		15	54	46	63

This schedule is given for information only and is applicable to thickness < 38 mm.

It must be used in compliance with the code of practice.

For thickness from 38 to 75 mm , the air relative humidity should be increased by 5 % at each step.

For thickness over 75 mm , a 10 % increase should be considered.

Note: Must be dried slowly and carefully in order to reduce defects, especially collapse with thick material. Quartersawn recommended.

SAWING AND MACHINING

Blunting effect:	Normal
Sawteeth recommended:	Ordinary or alloy steel
Cutting tools:	Ordinary
Peeling:	Good
Slicing:	Not recommended or without interest
Note:	Keep sharp cutters to avoid fuzzy surfaces.

ASSEMBLING

Nailing / Screwing:	Poor
Gluing:	Correct

END-USES

Main known end-uses; they must to be implemented according to the code of practice.

Important remark: some end-uses are mentionned for information (traditional, regional or ancient end-uses).

Veneer for interior of plywood
Veneer for back or face of plywood
Interior joinery
Boxes and crates
Formwork
Interior panelling
Blockboard
Fiber or particle boards
Current furniture or furniture components
Moulding
Turned goods
Glued laminated
