

REQUIREMENT OF A PRESERVATIVE TREATMENT

Against dry wood borer attacks:	Does not require any preservative treatment
In case of temporary humidification risk:	Requires appropriate preservative treatment
In case of permanent humidification risk:	Use not recommended

DRYING

Possible drying schedule

Drying rate:	Normal	Temperature (°C)			Air humidity (%)
		M.C. (%)	dry-bulb	wet-bulb	
Risk of distortion:	High risk				
Risk of casehardening:	No				
Risk of checking:	Slight risk	Green	50	47	84
Risk of collapse:	No	40	50	45	75
		30	55	47	67
		20	70	55	47
		15	75	58	44

This schedule is given for information only and is applicable to thickness < 38 mm.

It must be used in compliance with the code of practice.

For thickness from 38 to 75 mm , the air relative humidity should be increased by 5 % at each step.

For thickness over 75 mm , a 10 % increase should be considered.

Note: Thin stock must be dried with care to prevent distortions.

SAWING AND MACHINING

Blunting effect:	Fairly high
Sawteeth recommended:	Stellite-tipped
Cutting tools:	Tungsten carbide
Peeling:	Not recommended or without interest
Slicing:	Not recommended or without interest
Note:	Resin may clog the tools and may have a blunting effect. Filing is recommended to obtain a good finish.

ASSEMBLING

Nailing / Screwing:	Good but pre-boring necessary
Gluing:	Correct
Note:	Risk of splitting when nailing.

END-USES

Main known end-uses; they must to be implemented according to the code of practice.

Important remark: some end-uses are mentionned for information (traditional, regional or ancient end-uses).

Industrial or heavy flooring
 Flooring
 Vehicle or container flooring
 Ship building (ribs)
 Exterior joinery
 Interior joinery
 Interior panelling
 Exterior panelling
 Current furniture or furniture components