
REQUIREMENT OF A PRESERVATIVE TREATMENT

Against dry wood borer attacks:	Requires appropriate preservative treatment
In case of temporary humidification risk:	Requires appropriate preservative treatment
In case of permanent humidification risk:	Use not recommended

DRYING

Possible drying schedule

Drying rate:	Rapid	Temperature (°C)			Air humidity (%)
		M.C. (%)	dry-bulb	wet-bulb	
Risk of distortion:	Slight risk	Green	50	47	84
Risk of casehardening:	No	40	50	45	75
Risk of checking:	Slight risk	30	55	47	67
Risk of collapse:	No	20	70	55	47
		15	75	58	44

This schedule is given for information only and is applicable to thickness < 38 mm.

It must be used in compliance with the code of practice.

For thickness from 38 to 75 mm , the air relative humidity should be increased by 5 % at each step.

For thickness over 75 mm , a 10 % increase should be considered.

Note: Drying requires care. Risks of blue stain. Risks of distortion in presence of tension wood.

SAWING AND MACHINING

Blunting effect:	Normal
Sawteeth recommended:	Ordinary or alloy steel
Cutting tools:	Ordinary
Peeling:	Good
Slicing:	Not recommended or without interest
Note:	The presence of tension wood may cause overheating and blunting of sawblades. Risks of woolliness, keep sharp edges.

ASSEMBLING

Nailing / Screwing:	Poor
Gluing:	Correct

END-USES

Main known end-uses; they must to be implemented according to the code of practice.

Important remark: some end-uses are mentionned for information (traditional, regional or ancient end-uses).

Note: This wood can be used for shingles if treated.

Matches

Veneer for interior of plywood

Boxes and crates

Current furniture or furniture components

Interior joinery

Interior panelling

Moulding

Light carpentry

Glued laminated

Blockboard

Turned goods
