



---

---

## TAUARI

---

### REQUIREMENT OF A PRESERVATIVE TREATMENT

---

Against dry wood borer attacks:	Requires appropriate preservative treatment
In case of temporary humidification risk:	Requires appropriate preservative treatment
In case of permanent humidification risk:	Use not recommended

---

### DRYING

#### Possible drying schedule

Drying rate:	Rapid	Temperature (°C)			Air humidity (%)
		M.C. (%)	dry-bulb	wet-bulb	
Risk of distortion:	No risk or very slight risk				
Risk of casehardening:	No				
Risk of checking:	No risk or very slight risk				
Risk of collapse:	No	30	42	41	94
		25	42	39	82
		20	48	43	74
		15	48	43	74

This schedule is given for information only and is applicable to thickness < 38 mm.

It must be used in compliance with the code of practice.

For thickness from 38 to 75 mm , the air relative humidity should be increased by 5 % at each step.

For thickness over 75 mm , a 10 % increase should be considered.

Note: Must be dried as soon as possible after felling to avoid blue stain.

---

### SAWING AND MACHINING

---

Blunting effect:	High
Sawteeth recommended:	Stellite-tipped
Cutting tools:	Tungsten carbide
Peeling:	Good
Slicing:	Good

---

### ASSEMBLING

---

Nailing / Screwing:	Good but pre-boring necessary
Gluing:	Correct

---

### END-USES

Main known end-uses; they must to be implemented according to the code of practice.

Important remark: some end-uses are mentionned for information (traditional, regional or ancient end-uses).

---

Stairs (inside)

Veneer for back or face of plywood

Blockboard

Moulding

Interior panelling

Boxes and crates

Formwork

Exterior joinery

Interior joinery

Current furniture or furniture components

Light carpentry

Glued laminated

Flooring

Turned goods

Seats

Sliced veneer

Veneer for interior of plywood

---